


# **COOKTOP PARTS**


For Models: SF367LSXQ0, SF367LXSB0, SF367LXSS0 (Designer White) (Black) (Stainless Steel)

30" GAS FREESTANDING SELF CLEAN RANGE SEALED BURNER



Illus No.	. Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	9762973 W10041640 9762997	French Installation Instructions Anti-Tip Template English/Spanish English/French Safer Cooking Tips English French Cap, Burner LF & RF Grey Black LR Grey Black RR Grey Grey	4 5 6 7	4455981	Cooktop White Black Panel, Manifold White Black Knob, Control (2) White	8 9 11 12 14 15	8273108 8273103 8273112 8273111 8522850 8522851 8522847 8522846 3400701 3196557	Knob, Powerburner (2) White Black Grate, Burner (4) Grey Black Grate, Center Gray Black Screw


# **CONTROL PANEL PARTS**



Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTIO
1		Endcap, Left Hand	5	9758080	Module, Spark	13	3196178	Screw
	W10009040		8		Cover, Upper	14	9757609	Nameplate
	W10009080	Black	9		Shield, Heat	15	9762726	Brkt-Mntg, DSI
		Endcap, Right Hand	10		Cover, Lower	16		Brkt-Mntg,Conso
	W10009050		11		Bracket, Support	19	8273564	Clip
	W10009090	Black	12		Control, Range			•
3		Panel, Control		9762193				
	9762091	White		9762194	Black			
	9762093	Black						
	9762094	Stainless Model						

# **MANIFOLD PARTS**

For Models: SF367LSXQ0, SF367LXSB0, SF367LXSS0 (Designer White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# **MANIFOLD PARTS**

For Models: SF367LSXQ0, SF367LXSB0, SF367LXSS0 (Designer White) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
2		Burner Base
	8273700	Large (3)
3	8273701	Small (1) Tubing, Burner
3		W/Orifice
	8273693	Left Front
	8273694	Left Rear
	8273696	Right Front
4	8273697 8523402	Right Rear Tubing (Manifold
4	0023402	to Regulator)
5	8523406	Harness, Igniter
		(W/Switches)
6	8523793	Electrode (4)
7	8523407	Pipe, Manifold
8	9757218	Valve LF – RF – LR
	8273004	Right Rear
9	8273060	Nut (4)
10	8273062	Screw (4)
11	3400228	Bolt
12 13	8054078 8053970	Burner, Broiler Spreader, Flame
13	0033310	(Oven)
14	9758078	Burner, Bake
15	9761959	Valve/Regulator
16	0054400	Igniter
	8054129 9758079	Broil Bake
17	8272222	Tubing (Broiler
		Fitting To Valve)
18	3186489	Fitting, Broiler
19	8272403	Cover, Igniter
20	8273064	Orifice, Burner Left Front
	8273064	Right Front
	8273065	Left Rear
	8273067	Right Rear
21	8053262	Spreader, Flame
23	3196265	(Broiler) Screw
23 24	3196265	Screw
25	3196385	Screw
26	3400016	Screw

Following Parts Not Illustrated

8523420 Spuds, LP Gas (Kit of 4)

# **CHASSIS PARTS**

For Models: SF367LSXQ0, SF367LXSB0, SF367LXSS0 (Designer White) (Black) (Stainless Steel)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# **CHASSIS PARTS**


Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
		DECORAL FICK		1101	DEGGILLI HOR		1101	DECORAL HOR
1	W10012240		17	9760407	Brkt – Mounting	36	3196439	Button, Plug
2	8272747	Shield, Flue	18	W10008830	Seal, Oven Flange	37	3196178	Screw
3	8273036	Burner Box	19	9758701	Spacer, Door	38	3196152	Screw
4		Panel, Side (2)	20		Back, Main	39		Screw
	8053830	White-Textured	21	8522416	Seal, Oven		3196166	White
	8053832	Black	22	8053971	Brace, Main Back		3196168	Black
5	9761490	Insulation	23		Retainer, Insul.	40	3196176	Screw
6	8523249	Brkt, Manifold Mtg		9761449	Left Hand	42	3196179	Screw
7	9761512	Clip, Mounting		9761448	Right Hand	44	3196177	Screw
8		Frame, Front	24		Clip, Panel (6)	45	3196168	Screw
		(Not Serviced)	25		Cord, Power	46	3196560	
9	3196037	Foot, Front (2)	26		Rod – Dr Switch	47	3196160	
10	9761935	Foot, Rear (2)	27	9757262	Switch, Door			
11	3195097	Bottom, Oven	28	3196701	Light Socket Assy	INSU	LATION	
12	8273902	Sensor, Oven	29		Bulb, Oven Light			
13	8053967	Baffle, Burner	30		Latch, Door		8524099	Insulation, Wrap
14		Shield, Heat	31		Rod, Latch			Insulation, Vent
15		Shield, Lower	32		Latch–Mtr		8272614	Insulation, Back
16		Rail, Base (2)	33		Glide, Drawer			,
		, ( )	34	W10031780	•			

# **DRAWER & BROILER PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Rack, Oven (2)	7		Panel, Drawer Frnt	13	9761033	Liner, Drawer
4	9761031	Drawer, Storage		8053336	White	14	8053334	Spacer, Glide
5	3196817	Bracket, Drawer(2)		8053338	Black	15		Panel, Stainless
6		Rivet, Push (2)	10	3196168	Screw	16	9757219	Handle, Stainless
	3196814	White				17	9781235	•
	3196813	Black						

# **DOOR PARTS**



Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION
1		Trim, Top	10	9761493	Hinge, Door	14	3196160	Screw
	9761975	•			Stainless Model	15	3196025	Clip, Door Glass
	9762391	Black	11	9761357	Retainer, Insul.	18	W10031780	
	9762394	Stainless Model	12		Trim, Door Side	19		Trim, Bottom
2	3196164	Screw			Left Hand		8523175	White
3		Handle, Door		8523172	White		8523177	Black
	9761982			8523171	Black		8523180	Stainless Model
	9761983	Black			Right Hand	21	3196794	Bracket, Window
4	9761344	Liner, Door		8523166	White	22	3196165	Screw
5	W10031790	Screw		8523165	Black	23	9761517	Clip, Door Mntg(2)
6	9758162	Glass, Inner (2)	13		Glass, Outer Door			0 ( )
7	3186289	Frame, Glass		9762479	White			
9	8272618	Insulation, Door		9762480	Black			
				9756435	Stainless Model			

### **OPTIONAL PARTS (NOT INCLUDED)**

For Models: SF367LSXQ0, SF367LXSB0, SF367LXSS0 (Designer White) (Black) (Stainless Steel)

No. No. DESCRIPTION

Parts Not Illustrated and

Parts Not Illustrated and Optional Parts (Not Included)

### SPLICING WIRES--25FT. LENGTH

Part

Illus.

242828 Wire, Black 12 Ga. 150° c 242821 Wire, Blue 14 Ga. 150°c 242822 Wire, Brown 14 Ga. 150°c 242830 Wire, Brown 14 Ga. 200°c 242823 Wire, Green 14 Ga. 150°c 242824 Wire, Orange 14 Ga. 150°c 242825 Wire, Red 14 Ga. 150°c 242831 Wire, Red 14 Ga. 200°c 242827 Wire, Yellow

### **REFINISHING MATERIAL**

799832 Kit, Porcelain Repair (White) 242756 Touch-Up Self-Clean(1/2 Pt) 261582 Grease

14 Ga. 150°c

Illus. Part No. No. DESCRIPTION

### INSULATION

261514 Insulation, Fiberglass (1–1/2" x 24" x 120") 240132 Insulation, Fiberglass (2–1/2" x 22" x 120")

### PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 511873 White Porcelain (2 Oz.)

# PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White 4392901 Biscuit 285006 Superior Black 206922 Primer (White)

### PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut) Illus. Part No. No. DESCRIPTION

### **ACCESSORY PARTS**

241430 Foil, Aluminum Oven (18" x 25') 4396923 Pan – Broiler

### **ANTI-TIP KIT**

W10017440 Anti-Tip Kit

### **WIRING HARNESS PARTS**

9762433 Harness, Main 8524207 Harness, Bake & Broil Ignitor 8523599 Harness, Wire (Cooktop Spark) W10045060 Harness, Grnd DSI 3196174 Screw, Ground 3196520 Clip, Wire 3196896 Clip, Wire 313438 Clip, Harness 3196173 Screw 3195927 Wire, Tie 3196696 Clip, Harness